


# argoTrackPilot – quick start guide

## Preparation


1. Choose track from ECDIS or in TrackPilot



2. Choose profile



3. Set stream velocity




4. Check track and filter




5. Turn on trackpilot mode

## Oscillations

! Oscillations around guiding line




! Check stream settings




Test for a few minutes and adjust further if necessary

## Permanent track deviation

! Permanent track deviation



! Check stream settings



No



Autopilot reaches rate of turn setpoint and stays inside the valid range (blue)

Yes




1. Increase „Rudder“ on autopilot
2. Increase „Controller Gain“ on trackpilot
3. Check rate of turn signal


## Deviation in curves

! Check stream settings


Too far on inside of curve



Too far on outside of curve



Change drift gain




Test for a few minutes and adjust further if necessary

## Miscellaneous


Checking system version




Open access for remote support




Restarting trackpilot (and touchscreen)



Variant B)



Watch alarm settings



Download manual



Customer support:  
+49 711 25253721 argonics

# argoTrackPilot – warnings and alarms

Warning Name	Action	Alarm Name	Action
Close to end of track	<ul style="list-style-type: none"> <li>Switch to manual steering</li> <li>Choose new guiding line</li> </ul>	Track too far away	<ul style="list-style-type: none"> <li>Switch to manual steering</li> <li>Check if the correct guiding line has been chosen</li> <li>Choose another line closer to the current position</li> </ul>
Position inaccurate	<ul style="list-style-type: none"> <li>Wait for the warning to disappear</li> <li>If EstimationDegraded error comes up switch to manual steering</li> </ul>	End of track reached	<ul style="list-style-type: none"> <li>Immediately switch to manual steering</li> <li>Choose new guiding line</li> </ul>
Distance to track large	<ul style="list-style-type: none"> <li>Check if the autopilot system processes the commands by the track control system</li> <li>Acknowledge warning</li> </ul>	Turn too sharp	<ul style="list-style-type: none"> <li>Switch to manual steering</li> <li>Check guiding line for errors (points very close together)</li> <li>Choose new guiding line</li> </ul>
GPS (2): No position received	<ul style="list-style-type: none"> <li>Acknowledge warning</li> <li>Closely monitor track control system for correct operation</li> <li>Increase attention</li> <li>Wait if data comes back</li> <li>otherwise switch to manual steering</li> </ul>	Rudder change too large	<ul style="list-style-type: none"> <li>Acknowledge alarm by switching to manual steering.</li> <li>Wait until state of track control system returns to „READY“.</li> <li>Check in ECDIS if ship position on map and reality match.</li> <li>Switch on track control system</li> <li>Increase attention</li> </ul>
GPS (2): No velocity received	<ul style="list-style-type: none"> <li>Acknowledge warning and closely monitor track control system for correct operation</li> <li>Error persists after 10 minutes? ➔ Contact support, if nec. switch to manual steering</li> </ul>	Position unusable	<ul style="list-style-type: none"> <li>Acknowledge alarm by switching to manual steering. There is no other way to acknowledge the alarm.</li> <li>Wait until state of track control system returns to „READY“.</li> <li>Check in ECDIS if ship position on map and reality match.</li> <li>Switch on track control system</li> <li>Increase attention</li> </ul>
GPS (2): No heading received	<ul style="list-style-type: none"> <li>Acknowledge warning and closely monitor track control system for correct operation</li> <li>Error persists after 10 minutes? ➔ Contact support, if nec. switch to manual steering</li> </ul>	Dead man alarm	<ul style="list-style-type: none"> <li>Acknowledge alarm by switching to manual steering.</li> <li>Activate TrackPilot mode again</li> </ul>
Velocity low	<ul style="list-style-type: none"> <li>Increase velocity</li> <li>Acknowledge warning</li> </ul>	Target too close	<ul style="list-style-type: none"> <li>Acknowledge alarm</li> <li>Continue manually and increase distance to AIS target or deactivate TargetPilot</li> </ul>
Dead man warning	<ul style="list-style-type: none"> <li>Move Track or click any button on the touch display</li> </ul>	Target lost	<ul style="list-style-type: none"> <li>Acknowledge alarm by switching to manual steering. There is no other way to acknowledge the alarm.</li> <li>Continue manually and select new AIS target or deactivate TargetPilot</li> </ul>
Target close	<ul style="list-style-type: none"> <li>Decrease velocity or deactivate TargetPilot or select different target</li> </ul>	Collision ahead	<ul style="list-style-type: none"> <li>Acknowledge alarm by switching to manual steering. There is no other way to acknowledge the alarm.</li> <li>Continue to steer manually and avoid collision</li> <li>In case of false alarm, check the setting of the argoLaneWarning</li> </ul>
Target lost	<ul style="list-style-type: none"> <li>Closely monitor track control system for correct operation</li> </ul>	Autopilot connection lost	<ul style="list-style-type: none"> <li>Switch off immediately</li> <li>Check correct function of all devices</li> <li>Contact customer support</li> </ul>
AIS: No data received	<ul style="list-style-type: none"> <li>TargetPilot active? ➔ Closely monitor track control system for correct operation</li> <li>Malfunction of AIS? ➔ immediately deactivate TargetPilot</li> </ul>	I/O: Error - Contact support	<ul style="list-style-type: none"> <li>Switch off immediately</li> <li>Check correct function of all devices</li> <li>Contact customer support</li> </ul>
Collision ahead	<ul style="list-style-type: none"> <li>Move current track</li> <li>Wait until the ship has reached the shifted line</li> </ul>	System Error 001/002/003 - Contact support	<ul style="list-style-type: none"> <li>Switch off immediately</li> <li>Contact customer support</li> </ul>
Power supply connected incorrectly	<ul style="list-style-type: none"> <li>Contact dealer/installer</li> </ul>		
TrackPilot switched off	<ul style="list-style-type: none"> <li>Activate TrackPilot again if required</li> <li>Check correct function of all devices</li> </ul>		
End of SafetyContour ahead	<ul style="list-style-type: none"> <li>Select new safety corridor</li> </ul>		
PS/SB limit violated	<ul style="list-style-type: none"> <li>Move the track to keep the planned path within the safety corridor</li> </ul>		
No ROT received	<ul style="list-style-type: none"> <li>Check the correct function of all devices.</li> <li>If this warning does not disappear by itself, contact support.</li> </ul>		
ECDIS / Alphantron Display: connection lost	<ul style="list-style-type: none"> <li>(Re-)Start the ECDIS / Alphantron Display.</li> <li>If this warning does not disappear by itself, contact support.</li> </ul>		
AIS: Error - Contact support	<ul style="list-style-type: none"> <li>(Re-)Start the AIS.</li> <li>If the warning does not disappear by itself, contact support.</li> </ul>		